



Alfa Romeo Stelvio Side Skirt Trim Kit - Carbon Fiber Installation Instructions



This product is designed to cover
the OEM Side Skirts.

Clean the inner part of the
product with sandpaper.
Add adhesive to the
corners as shown in the
image in red.

We recommend
Black Silicon Bodywork
Glue such as 3M or Wurth.



Attach the piece and allow the glue to harden.