



Alfa Romeo Stelvio Front Splitter - Quadrifoglio - Carbon Fiber

Installation Instructions



This product is installed with adhesive and screws.

The red lines in the photo below show the places you need to add adhesive to.



We recommend Black Bodywork Silicone Glue such as 3M or Wurth.

The yellow circles show where the screws go.



Attach the piece and allow for the adhesive to harden.