



Alfa Romeo Stelvio Rear Diffuser - Quadrifoglio - Carbon Fiber Installation Instructions



This product is designed to cover the OEM Rear Diffuser.

Clean the inner part of the product with sandpaper. Add adhesive to the corners as shown in the image in red. The yellow circles show you the placement of the screws.



We recommend Black Silicon Bodywork Glue such as 3M or Wurth.



Attach the piece and allow the glue to harden.