



Alfa Romeo Stelvio Diffuser Frame - Quadrifoglio - Carbon Fiber Installation Instructions



This product is designed to cover the OEM Diffuser Frame.



Clean the inner part of the product with sandpaper.
Add adhesive to the corners as shown in the image in red.

We recommend
Black Silicon Bodywork
Glue such as 3M or Wurth.

Attach the piece and allow the glue to harden.